

## M3 Remote Command List

Description	Command		Full RS232 Command	
	Hex	Dec	Hex	Dec
Power On	25	37	01,16,25,02,C4	1,22,37,2,196
Power Off	C8	200	01,16,C8,02,21	1,22,200,2,33
Disc	89	137	01,16,89,02,60	1,22,137,2,96
CD	85	133	01,16,85,02,64	1,22,133,2,100
Tuner	DD	221	01,16,DD,02,5E,4C	1,22,221,2,94,76
Video 4	C2	194	01,16,C2,02,27	1,22,194,2,39
Video 5	8D	141	01,16,8D,02,5C	1,22,141,2,92
Cinema	91	145	01,16,91,02,58	1,22,145,2,88
Balanced	9B	155	01,16,9B,02,4E	1,22,155,2,78
Speaker A - Main	CE	206	01,16,CE,02,1B	1,22,206,2,27
Speaker B - Remote	CF	207	01,16,CF,02,1A	1,22,207,2,26
Surround Mode	CC	204	01,16,CC,02,1D	1,22,204,2,29
Mute	94	148	01,16,94,02,55	1,22,148,2,85
Balance	3D	61	01,16,3D,02,AC	1,22,61,2,172
Volume Up	88	136	01,16,88,02,61	1,22,136,2,97
Tone	39	57	01,16,39,02,B0	1,22,57,2,176
Crossover	3C	60	01,16,3C,02,AD	1,22,60,2,173
Volume Down	8C	140	01,16,8C,02,5D	1,22,140,2,93
Zone Power On	B0	176	01,16,B0,02,39	1,22,176,2,57
Zone Power Off	B1	177	01,16,B1,02,38	1,22,177,2,56
Zone Disc	A6	166	01,16,A6,02,43	1,22,166,2,67
Zone CD	A5	165	01,16,A5,02,44	1,22,165,2,68
Zone Tuner	AF	175	01,16,AF,02,3A	1,22,175,2,58
Zone Video 1 (DVD)	A8	168	01,16,A8,02,41	1,22,168,2,65
Zone Tape 1	AE	174	01,16,AE,02,3B	1,22,174,2,59
Zone Tape 2	B9	185	01,16,B9,02,30	1,22,185,2,48
Zone Aux	A7	167	01,16,A7,02,42	1,22,167,2,66
Zone Mute	A0	160	01,16,A0,02,49	1,22,160,2,73