

## M5 Remote Command List

Description	Command		Full RS232 Command	
	Hex	Dec	Hex	Dec
2 Channel	61	97	01,16,61,02,88	1,22,97,2,136
CD	59	89	01,16,59,02,90	1,22,89,2,144
CD Filter	1C	28	01,16,1C,02,CD	1,22,28,2,205
Clear	50	80	01,16,50,02,99	1,22,80,2,153
Cursor Down	5F	95	01,16,5F,02,8A	1,22,95,2,138
Cursor Enter	19	25	01,16,19,02,D0	1,22,25,2,208
Cursor Left	5D	93	01,16,5D,02,8C	1,22,93,2,140
Cursor Right	5E	94	01,16,5E,5E,02,8B	1,22,94,94,2,139
Cursor Up	5C	92	01,16,5C,02,8D	1,22,92,2,141
Digit 0	16	22	01,16,16,02,D3	1,22,22,2,211
Digit 1	0C	12	01,16,5E,4C,02,DD	1,22,94,76,2,221
Digit 2	0D	13	01,16,5E,4D,02,DC	1,22,94,77,2,220
Digit 3	0E	14	01,16,5E,4E,02,DB	1,22,94,78,2,219
Digit 4	0F	15	01,16,5E,4F,02,DA	1,22,94,79,2,218
Digit 5	10	16	01,16,5E,50,02,D9	1,22,94,80,2,217
Digit 6	11	17	01,16,5E,51,02,D8	1,22,94,81,2,216
Digit 7	12	18	01,16,5E,52,02,D7	1,22,94,82,2,215
Digit 8	13	19	01,16,5E,53,02,D6	1,22,94,83,2,214
Digit 9	15	21	01,16,15,02,D4	1,22,21,2,212
Dimmer	58	88	01,16,58,02,91	1,22,88,2,145
Index Back	E8	232	01,16,E8,02,5E,41	1,22,232,2,94,65
Index Forward	E9	233	01,16,E9,02,5E,40	1,22,233,2,94,64
Level	E5	229	01,16,E5,02,5E,44	1,22,229,2,94,68
Menu	E6	230	01,16,E6,02,5E,43	1,22,230,2,94,67
Multi Channel	5B	91	01,16,5B,02,8E	1,22,91,2,142
Open/Close	48	72	01,16,48,02,A1	1,22,72,2,161
Pause	4A	74	01,16,4A,02,9F	1,22,74,2,159
Play	01	1	01,16,5E,41,02,E8	1,22,94,65,2,232
Power Off	3F	63	01,16,3F,02,AA	1,22,63,2,170
Power On	3E	62	01,16,3E,02,AB	1,22,62,2,171
Program	0B	11	01,16,5E,4B,02,DE	1,22,94,75,2,222
Random	03	3	01,16,5E,43,02,E6	1,22,94,67,2,230
Repeat	0A	10	01,16,5E,4A,02,DF	1,22,94,74,2,223
Repeat A-B	09	9	01,16,5E,49,02,E0	1,22,94,73,2,224
SACD	40	64	01,16,40,02,A9	1,22,64,2,169
Scan Back	04	4	01,16,5E,44,02,E5	1,22,94,68,2,229
Scan Forward	07	7	01,16,5E,47,02,E2	1,22,94,71,2,226
Setup	E7	231	01,16,E7,02,5E,42	1,22,231,2,94,66
Skip Back	05	5	01,16,5E,45,02,E4	1,22,94,69,2,228
Skip Forward	06	6	01,16,5E,46,02,E3	1,22,94,70,2,227
Stop	02	2	01,16,5E,42,02,E7	1,22,94,66,2,231
Text	4F	79	01,16,4F,02,9A	1,22,79,2,154
Time	08	8	01,16,5E,48,02,E1	1,22,94,72,2,225
Video On/Off	5A	90	01,16,5A,02,8F	1,22,90,2,143

Note: IR commands use NEC encoding with customer code 877C (34684)