

DENON Handy Hint

Pure Direct Mode



Pure direct mode:

Pure direct mode allows listeners to enjoy pure music of remarkably high quality.

When Pure Direct is selected, power to the video circuitry and the fluorescent display is turned off.

During analog sound input, power to the digital circuitry is also turned off, and adverse influences by other circuits on the audio circuitry are suppressed to the maximum extent possible.

Pure Direct mode makes sure your Denon AV Receiver is just as capable when used as a Hi-Fi amplifier.

